



Read these instructions before commencing installation. Please give these instructions to the owner/occupier after installation to retain for future reference/maintenance.

IP44 240V~50Hz 5W

These fittings are Class I and must be Earthed

Important Information

It is recommended that these luminaires are installed and fitted by a qualified electrician ensuring the installation complies with current wiring regulations & local building control. These products are designed for connection to a 240V~50Hz supply. Any faulty, broken or damaged luminaires should be replaced immediately. KSR will not accept responsibility for any claims arising from a poor installation. Please Note: The limited warranty shall be deemed null and void in the following circumstances: Failure by the installer, end user or any third party to exercise caution to protect any covered product or part from outside damage, adverse temperature (normal operating ambient temperature 0 - +35°C), humidity conditions, fluctuations in the electrical system or physical abuse as well as failure related to workmanship in the installation of the products or parts.

Important User Advice

Always switch off mains supply before servicing. This luminaire is suitable for indoor use. Do not use Megger or similar high voltage instruments. Due to the fact this luminaire contains electronic components that maybe damaged by high test voltages, they must be disconnected from the circuit before testing. To prevent damage to the driver, do not mix with conventional magnetic ballasts on the same electrical circuit. At the end of life the luminaire is classed as WEEE under directive 2014/30/EU and should be disposed of in accordance with local legislation

Installation Procedure

Familiarize yourself with the luminaire/installation procedure and ensure the power is safely isolated before installing the luminaire.

Locate Area(s) suitable for installation. Loosen the bottom allen bolt with the allen key provided, remove the Back / fixing plate and disconnect the plug connector as shown in Fig.1. Fix the back / fixing plate to the surface using the fixings provided, Push suitable cable through Grommet provided, being careful to make a small hole in grommet as to ensure a good seal between supply cable and grommet. Connect the mains 240V~50Hz supply (Fig.2) into Live (L) Brown, Earth (⊕) and Neutral (N) Blue terminals on the terminal block. Ensure the colour temperature required is selected via the CCT switch just inside the back of the fitting. Plug the connector back together and refit the main body to the luminaire using the allen bolt loosened in the first stage. Turn on Power and Test Luminaire

Fitting output details - 5W LED				
Product Code	Lumen output & CRI Details			
	2700K		3000K	
KSR7350	230lm	90	250lm	90
KSR7351	230lm	90	250lm	90
KSR7352	230lm	90	250lm	90

This product contains a light source of energy efficiency class F, The LED light source and Control Gear in this product is Non-replaceable.

